

Troubleshooting

Every time I create a setup using Auto Setup, I always have to either double my duration time or cut my count value in half in order to get the proper amount of fluid. What can I change so that any future setups that I create will have enough fluid?

If you continually have to adjust your duration and count values to get the right amount of fluid, change your Film Thickness parameter in the Configure Auto Setup menu to reflect the changes you have to make. For example, if you always have to double the amount of fluid after creating a setup, double your Film Thickness parameter. **NOTE:** If you change an Auto Setup parameter, it will only affect setups created after the change. The change will not have any affect on existing setups.

Unique solution ID: #1061

Author: Unist

Last update: 2020-03-11 15:29